ROJO PARTFILL

PRODUCT INFO





SAI Global



Description


RoJo Part Fill is a low flow valve intended for use in rain water harvesting tanks. The purpose of the float valve is to automatically maintain a low level of water in the tank during periods of no or low rainfall. This allows services fed by the tank to continue while leaving capacity in the tank for refilling by the next rain.

Applications

Maintaining water levels in:

- · Rain water harvesting tanks
- · Water cisterns
- Irrigation and process applications.

Flow Graph



Outline of Operation

- The valve is installed through the side wall of a storage tank. It should be mounted above the overflow level of the tank to prevent backflow.
- As the tank empties the weighted float travels down the cord and sits on the bottom stop to activate the valve.
- The valve will run until the weighted float lifts clear of the bottom stop.
- The float will then rise as rainwater fills the tank and falls as the tank water is used.
- The valve will only function at times when rain fall is insufficient to maintain a water level in the tank above the bottom stop.
- The use of a flow restrictor before the valve will not cause the valve to malfunction.

Features

- Ideal for use with all makes and models of rain water harvesting tanks
- Compatible with trickle flow restrictors
- Compact
- Constructed from non corroding materials
- Built in non return valve
- Valve can be locked in off position using the lock off switch


Available Inlet Sizes

15mm (1/2") 20mm (3/4")

All supplied with long tail thread with back nut.

Pressure Range

0 - 10 Bar (0 - 150 psi)



Note: Keep overflow, rain water inlet and outlet to pressure pump as far away from the float valve as possible.

ROJO PARTFILL DIMENSIONS & MATERIALS






Partfill







Rojo Dimensions				
	mm	inches		
Α	210	8 1/4		
В	40	1 9/16		
С	59	2 5/16		
D	56	2 3/16		
E	208	8 3/16		
F	62	2 7/16		
G	20	12/16		
Н	38	1 1/2		
(

Materials			
Valve Body Tail & Nut	ABS		
Arm Extension Arms Internal Grey Mouldings	Glass Filled Nylon		
Yellow Valve Parts Filter	Acetal		
Float	HDPE		
Springs Bolts Nuts	304 Stainless Steel		
O' Rings	Nitrile		
Float Cord	Polyester		

Maximum Temperature of Operation 45°C, 115°F

ROJO PARTFILL PARTS IDENTIFICATION SHEET






Partfill





	_		
	<u> </u>	CODE	DESCRIPTION
_ (4)	1	RJPP1	Float Assembly
3	2	RJPP2	Body Assembly
	3	RJPP3	Inner Cartridge Assy (PF)
	4	RJP415	15mm (1/2") Tail Assy
		RJP420	20mm (¾") Tail Assy
(2)		RJP420E	20mm (¾") Ezi Start Tail Assy
(1)			
1			
			<u> </u>



	CODE	DESCRIPTION
1	RJPP1010	Bottom Stop (PF)
2	RJPP1020	Weighted Float (PF)
3	RJPP1030	Cord (PF)
4	RJPP1040	Rojo Part Fill Long Arm

